



westerbergs ciconia & strix

Art: 20030310, 20030311, 20030312, 20030313, 20030314,
20030315, 20030340, 20030341, 20030342, 20030343,
20030344, 20030345



Westerbergs Badrum Svarvaregatan 5, Box 525, SE-301 80 Halmstad SVERIGE

Phone: SE +46 (35) 15 45 50 NO +47 69 35 15 40 FI +358 02 07 43 50 00

westerbergs.com

westerbergs ciconia & strix

Art: 20030310, 20030311, 20030312, 20030313, 20030314,
20030315, 20030340, 20030341, 20030342, 20030343,
20030344, 20030345



	art.no	beskrivning	description
1	-	BLANDARKROPP, EJ TILLGÄNGLIG SOM RESERVDEL	MIXER BODY, NOT AVAILABLE AS SPARE PART
2	-	BLANDARPIP, EJ TILLGÄNGLIG SOM RESERVDEL	MIXER SPOUT, NOT AVAILABLE AS SPARE PART
3	9600411	PERLATORHÅLLARE KÖKSBLANDARE BLANK ROSTFRI	AERATOR HOUSING POLISHED STAINLESS
	9600406	PERLATORHÅLLARE KÖKSBLANDARE MATT SVART	AERATOR HOUSING MATTE BLACK
	9600407	PERLATORHÅLLARE KÖKSBLANDARE BORSTAD MÄSSING	AERATOR HOUSING BRUSHED BRASS
	9600408	PERLATORHÅLLARE KÖKSBLANDARE BORSTAD BRONS	AERATOR HOUSING BRUSHED BRONZE
	9600409	PERLATORHÅLLARE KÖKSBLANDARE BORSTAD ROSTFRI	AERATOR HOUSING BRUSHED STAINLESS
	9600410	PERLATORHÅLLARE KÖKSBLANDARE BORSTAD SVARTKROM	AERATOR HOUSING BRUSHED BLACK CHROME
4	9600457	PERLATOR NEOPERL 40.2002.000	AERATOR NEOPERL 40.2002.000
5	9600404	INSATS MINGDI 35MM	CARTRIDGE MINGDI 35MM
6	9600449	DEKORRING KÖKSBLANDARE BLANK ROSTFRI	DECOR RING KITCHEN MIXER POLISHED STAINLESS
	9600450	DEKORRING KÖKSBLANDARE MATT SVART	DECOR RING KITCHEN MIXER MATTE BLACK
	9600451	DEKORRING KÖKSBLANDARE BORSTAD MÄSSING	DECOR RING KITCHEN MIXER BRUSHED BRASS
	9600452	DEKORRING KÖKSBLANDARE BORSTAD BRONS	DECOR RING KITCHEN MIXER BRUSHED BRONZE
	9600453	DEKORRING KÖKSBLANDARE BORSTAD ROSTFRI	DECOR RING KITCHEN MIXER BRUSHED STAINLESS
	9600454	DEKORRING KÖKSBLANDARE BORSTAD SVARTKROM	DECOR RING KITCHEN MIXER BRUSHED BLACK CHROME

Westerbergs Badrum Svarvaregatan 5, Box 525, SE-301 80 Halmstad SVERIGE

Phone: SE +46 (35) 15 45 50 NO +47 69 35 15 40 FI +358 02 07 43 50 00

westerbergs.com



	art.no	beskrivning	description
7	9600430	ENGREPPSHANDTAG WB KÖKSBLANDARE BLANK ROSTFRI	HANDLE BASIN MIXER WB KITCHEN MIXER POLISHED STAINLESS
	9600431	ENGREPPSHANDTAG WB KÖKSBLANDARE MATT SVART	HANDLE BASIN MIXER WB KITCHEN MIXER MATTE BLACK
	9600432	ENGREPPSHANDTAG WB KÖKSBLANDARE BORSTAD MÄSSING	HANDLE BASIN MIXER WB KITCHEN MIXER BRUSHED BRASS
	9600433	ENGREPPSHANDTAG WB KÖKSBLANDARE BORSTAD BRONS	HANDLE BASIN MIXER WB KITCHEN MIXER BRUSHED BRONZE
	9600434	ENGREPPSHANDTAG WB KÖKSBLANDARE BORSTAD ROSTFRI	HANDLE BASIN MIXER WB KITCHEN MIXER BRUSHED STAINLESS
	9600435	ENGREPPSHANDTAG WB KÖKSBLANDARE BORSTAD SVARTKROM	HANDLE BASIN MIXER WB KITCHEN MIXER BRUSHED BLACK CHROME
8	9600461	INSEKSKRUV M5x3 MED TÄCKBRICKA GRÅ KÖKSBLANDARE	ALLEN SCREW M5x3 WITH COVER FOR KITCHEN MIXER GREY
9	9600443	BOTTENRING KÖKSBLANDARE BLANK ROSTFRI	BASE RING KITCHEN MIXER POLISHED STAINLESS
	9600444	BOTTENRING KÖKSBLANDARE MATT SVART	BASE RING KITCHEN MIXER MATTE BLACK
	9600445	BOTTENRING KÖKSBLANDARE BORSTAD MÄSSING	BASE RING KITCHEN MIXER BRUSHED BRASS
	9600446	BOTTENRING KÖKSBLANDARE BORSTAD BRONS	BASE RING KITCHEN MIXER BRUSHED BRONZE
	9600447	BOTTENRING KÖKSBLANDARE BORSTAD ROSTFRI	BASE RING KITCHEN MIXER BRUSHED STAINLESS
	9600448	BOTTENRING KÖKSBLANDARE BORSTAD SVARTKROM	BASE RING KITCHEN MIXER BRUSHED BLACK CHROME
10	9600400	FIXERINGSGÄNGA 32 BLANDARE	THREADED FIXATION PART 32 FOR MIX- ERS
11	9600399	FIXERINGSMUTTER M32 BLANDARE	FIXATION NUT M32 FOR MIXERS
12	9600394	FLEXSLANG ANSLUTNING BLANDARE 500MM G3/8 PAR	FLEXIBLE HOSE FOR MIXER WATER IN- LET 500MM G3/8 2 PCS
13	9600456	INSEKSKRUV M5x5 MED TÄCKBRICKA GRÅ KÖKSBLANDARE	ALLEN SCREW M5x5 WITH COVER FOR KITCHEN MIXER GREY