westerbergs ciconia, strix & zenit XL

Art: 20030320, 20030321, 20030322, 20030323, 20030324, 20030325, 20030350, 20030351, 20030352, 20030353, 20030354, 20030355, 20030502, 20030503, 20030505



Westerbergs Badrum Svarvaregatan 5, Box 525, SE-301 80 Halmstad SVERIGE

Phone: SE +46 (35) 15 45 50 NO +47 69 35 15 40 FI +358 02 07 43 50 00

westerbergs.com

westerbergs ciconia, strix & zenit XL

Art: 20030320, 20030321, 20030322, 20030323, 20030324, 20030325, 20030350, 20030351, 20030352, 20030353, 20030354, 20030355, 20030502, 20030503, 20030505

	art.no	beskrivning	description
1	-	BLANDARKROPP, EJ TILLGÄNGLIG SOM RESERVDEL	MIXER BODY, NOT AVAILABLE AS SPARE PART
2	-	BLANDARPIP, EJ TILLGÄNGLIG SOM RESERVDEL	MIXER SPOUT, NOT AVAILABLE AS SPARE PART
3	9600483	MUNSTYCKE KÖKSBLANDARE PULL-OUT BLANK ROSTFRI	NOZZLE KITCHEN MIXER PULL-OUT POLISHED STAINLESS
	9600484	MUNSTYCKE KÖKSBLANDARE PULL-OUT MATT SVART	NOZZLE KITCHEN MIXER PULL-OUT MATTE BLACK
	9600485	MUNSTYCKE KÖKSBLANDARE PULL-OUT BORSTAD MÄSSING	NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BRASS
	9600486	MUNSTYCKE KÖKSBLANDARE PULL-OUT BORSTAD BRONS	NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BRONZE
	9600487	MUNSTYCKE KÖKSBLANDARE PULL-OUT BORSTAD ROSTFRI	NOZZLE KITCHEN MIXER PULL-OUT BRUSHED STAINLESS
	9600488	MUNSTYCKE KÖKSBLANDARE PULL-OUT BORSTAD SVARTKROM	NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BLACK CHROME
	9600542	MUNSTYCKE KÖKSBLANDARE PULL-OUT ZENIT BORSTAD MÄSSING	ZENIT NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BRASS
	9600543	MUNSTYCKE KÖKSBLANDARE PULL-OUT ZENIT BORSTAD BRONS	ZENIT NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BRONZE
	9600545	MUNSTYCKE KÖKSBLANDARE PULL-OUT ZENIT BORSTAD SVARTKROM	ZENIT NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BLACK CHROME
4	9600468	BACKVENTIL Ø15x16 DN15 KÖKSBLANDARE PULL-OUT	CHECK VALVE FOR KITCHEN MIXER PULL-OUT
5	9600404	INSATS MINGDI 35MM	CARTRIDGE MINGDI 35MM
6	9600449	DEKORRING KÖKSBLANDARE BLANK ROSTFRI	DECOR RING KITCHEN MIXER POLISHED STAINLESS
	9600450	DEKORRING KÖKSBLANDARE MATT SVART	DECOR RING KITCHEN MIXER MATTE
	9600451	DEKORRING KÖKSBLANDARE BORSTAD MÄSSING	DECOR RING KITCHEN MIXER BRUSHED BRASS
	9600452	DEKORRING KÖKSBLANDARE BORSTAD BRONS	DECOR RING KITCHEN MIXER BRUSHED BRONZE
	9600453	DEKORRING KÖKSBLANDARE BORSTAD ROSTFRI	DECOR RING KITCHEN MIXER BRUSHED STAINLESS
	9600454	DEKORRING KÖKSBLANDARE BORSTAD SVARTKROM	DECOR RING KITCHEN MIXER BRUSHED BLACK CHROME

westerbergs ciconia, strix & zenit XL

Art: 20030320, 20030321, 20030322, 20030323, 20030324, 20030325, 20030350, 20030351, 20030352, 20030353, 20030354, 20030355, 20030502, 20030503, 20030505

	art.no	beskrivning	description
7	9600462	HANDTAG WB KÖKSBLANDARE XL BLANK ROSTFRI	HANDLE KITCHEN MIXER PULL-OUT POLISHED STAINLESS
	9600463	HANDTAG WB KÖKSBLANDARE XL MATT SVART	HANDLE KITCHEN MIXER PULL-OUT MATTE BLACK
	9600464	HANDTAG WB KÖKSBLANDARE XL BORSTAD MÄSSING	HANDLE KITCHEN MIXER PULL-OUT BRUSHED BRASS
	9600465	HANDTAG WB KÖKSBLANDARE XL BORSTAD BRONS	HANDLE KITCHEN MIXER PULL-OUT BRUSHED BRONZE
	9600466	HANDTAG WB KÖKSBLANDARE XL BORSTAD ROSTFRI	HANDLE KITCHEN MIXER PULL-OUT BRUSHED STAINLESS
	9600467	HANDTAG WB KÖKSBLANDARE XL BORSTAD SVARTKROM	HANDLE KITCHEN MIXER PULL-OUT BRUSHED BLACK CHROME
8	9600461	INSEXSKRUV M5x3 MED TÄCKBRICKA GRÅ KÖKSBLANDARE	ALLEN SCREW M5x3 WITH COVER FOR KITCHEN MIXER GREY
9	9600470	BOTTENRING KÖKSBLANDARE XL BLANK ROSTFRI	BASE RING KITCHEN MIXER PULL-OUT POLISHED STAINLESS
	9600471	BOTTENRING KÖKSBLANDARE XL MATT SVART	BASE RING KITCHEN MIXER PULL-OUT MATTE BLACK
	9600472	BOTTENRING KÖKSBLANDARE XL BORSTAD MÄSSING	BASE RING KITCHEN MIXER PULL-OUT BRUSHED BRASS
	9600473	BOTTENRING KÖKSBLANDARE XL BORSTAD BRONS	BASE RING KITCHEN MIXER PULL-OUT BRUSHED BRONZE
	9600474	BOTTENRING KÖKSBLANDARE XL BORSTAD ROSTFRI	BASE RING KITCHEN MIXER PULL-OUT BRUSHED STAINLESS
	9600475	BOTTENRING KÖKSBLANDARE XL BORSTAD SVARTKROM	BASE RING KITCHEN MIXER PULL-OUT BRUSHED BLACK CHROME
10	9600459	FIXERINGSGÄNGA M34 BLANDARE	THREADED FIXATION PART M34 FOR MIXERS
11	9600458	FIXERINGSMUTTER M34 BLANDARE	FIXATION NUT M34 FOR MIXERS
12	9600394	FLEXSLANG ANSLUTNING BLANDARE 500MM G3/8 PAR	FLEXIBLE HOSE FOR MIXER WATER INLET 500MM G3/8 2 PCS
13	9600456	INSEXSKRUV M5x5 MED TÄCKBRICKA GRÅ KÖKSBLANDARE 2ST	ALLEN SCREW M5x5 WITH COVER FOR KITCHEN MIXER GREY 2PCS

westerbergs ciconia, strix & zenit XL

Art: 20030320, 20030321, 20030322, 20030323, 20030324, 20030325, 20030350, 20030351, 20030352, 20030353, 20030354, 20030355, 20030502, 20030503, 20030505

	art.no	beskrivning	description
14	9600477	OMSTÄLLARVRED KÖKSBLANDARE XL BLANK ROSTFRI	DIVERTER HANDLE KITCHEN MIXER PULL-OUT POLISHED STAINLESS
	9600478	OMSTÄLLARVRED KÖKSBLANDARE XL MATT SVART	DIVERTER HANDLE KITCHEN MIXER PULL-OUT MATTE BLACK
	9600479	OMSTÄLLARVRED KÖKSBLANDARE XL BORSTAD MÄSSING	DIVERTER HANDLE KITCHEN MIXER PULL-OUT BRUSHED BRASS
	9600480	OMSTÄLLARVRED KÖKSBLANDARE XL BORSTAD BRONS	DIVERTER HANDLE KITCHEN MIXER PULL-OUT BRUSHED BRONZE
	9600481	OMSTÄLLARVRED KÖKSBLANDARE XL BORSTAD ROSTFRI	DIVERTER HANDLE KITCHEN MIXER PULL OUT BRUSHED STAINLESS
	9600482	OMSTÄLLARVRED KÖKSBLANDARE XL BORSTAD SVARTKROM	DIVERTER HANDLE KITCHEN MIXER PULL OUT BRUSHED BLACK CHROME
15	9600455	INSATS DISKMASKINSAVSTÄNGNING KÖKSBLANDARE	CARTRIDGE DISHWASHER FUCTION KITCHEN MIXER
16	9600460	FLEXSLANG ANSLUTNING DISKM. KÖKS-BLANDARE 500MM G1/2	FLEXIBLE HOSE FOR DW CONNECTION KITCHEN MIXER 500MM G1/2
17	9600489	SLANG KÖKSBLANDARE PULL-OUT	HOSE KITCHEN MIXER PULL-OUT
18	9600469	SLANG KÖKSBLANDARE PULL-OUT KORT 230MM	HOSE KITCHEN MIXER PULL-OUT SHORT 230MM
19	9600547	KOPPLING SVART SLANG TILL KÖKSBLAN-DARE PULL-OUT	CONNECTOR BLACK FOR PULL-OUT HOSE KITCHEN MIXER
20	9600666	MOTVIKT KÖKSBLANDARE PULL-OUT	COUNTERWEIGHT KITCHEN MIXER PULL-OUT
21	9600667	HYLSA FÖR SLANG KÖKSBLANDARE PULL-OUT	HOSE PROTECTION KITCHEN MIXER PULL OUT
22	-	HANDTAGSPINNE TILL ZENIT KÖKSBLAN-DARE BORSTAD MÄSSING	ZENIT NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BRASS
	-	HANDTAGSPINNE TILL ZENIT KÖKSBLAN-DARE BORSTAD BRONS	ZENIT NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BRONZE
	-	HANDTAGSPINNE TILL ZENIT KÖKSBLAN-DARE BORSTAD SVARTKROM	ZENIT NOZZLE KITCHEN MIXER PULL-OUT BRUSHED BLACK CHROME